

# BLUETECHNIX


## Embedding Ideas

# Sentis3D-M421



## Quick Start Guide

Version 3





Bluetechnix

Waidhausenstraße 3/19  
A-1140 Vienna  
AUSTRIA

office@bluetechnix.com  
www.bluetechnix.com

Sentis3D-M421-Quick Start Guide

Document No.: 900-308 / A

Publication date: April 22, 2016

Subject to change without notice. Errors excepted.

This document is protected by copyright. All rights reserved. No part of this document may be reproduced or transmitted for any purpose in any form or by any means, electronically or mechanically, without expressly written permission by Bluetechnix GmbH.

Windows is a registered trademark of Microsoft.



## Table of Contents

1	Unboxing .....	5
1.1	In the box (Kit version) .....	5
1.2	Connecting your Sentis3D-M421 .....	5
1.2.1	Connector Overview .....	5
1.2.2	Power Connector (a) .....	6
1.2.3	GBit Ethernet Connector (b) .....	6
1.3	Overview of the Setup.....	7
2	Downloading the Evaluation Software .....	8
2.1	Support website .....	8
2.2	Start-up screen .....	9
2.3	Prepare your Network Interface Card (NIC) .....	9
3	Start using your Sentis3D-M421 with 'BlitToSuite' .....	10
4	System Requirements & Support.....	11
4.1	Support .....	11
5	Product History .....	12
5.1	Version Information .....	12
5.1.1	Sentis3D-M421 .....	12
5.2	Anomalies.....	12
5.3	Document Revision History .....	12



© Bluetechnix 2016

All Rights Reserved.

The information herein is given to describe certain components and shall not be considered as a guarantee of characteristics.

Terms of delivery and rights of technical change reserved.

We hereby disclaim any warranties, including but not limited to warranties of non-infringement, regarding circuits, descriptions and charts stated herein.

Bluetechnix makes and you receive no warranties or conditions, express, implied, statutory or in any communication with you. Bluetechnix specifically disclaims any implied warranty of merchantability or fitness for a particular purpose.

Bluetechnix takes no liability for any damages and errors causing of the usage of this board. The user of this board is responsible by himself for the functionality of his application. He is allowed to use the board only if he has the qualification. More information is found in the General Terms and Conditions (AGB).

Information

For further information on technology, delivery terms and conditions and prices please contact Bluetechnix (<http://www.bluetechnix.com>).

Warning

Due to technical requirements components may contain dangerous substances.



## 1 Unboxing

### 1.1 In the box (Kit version)

- Sentis3D-M421
- CAT5/7 Ethernet Cable
- Quick Start Guide
- Power Supply \*
- Mains cable
- Tripod



**\* Note**

The power supply's operating temperature is specified from 0 to +40°C. This represents not the effective working temperature of the camera!

### 1.2 Connecting your Sentis3D-M421

#### 1.2.1 Connector Overview

- a. Power Supply
- b. GBit Ethernet (RJ45) 10/100/1000 Base-T




Figure 1-1: Sentis3D-M4521 connectors and interfaces



**Note**

Please follow the next steps in the right order to get your Sentis3D-M421 up and running correctly.

## 1.2.2 Power Connector (a)

### Pin assignment on the power connector:

Connector Type: 2.1mm ID / 5.5mm OD

Voltage: 18-30V



**Note**  
! Use inherently limited power sources only!

The power supply connector is protected against wrong polarity but the Sentis3D-M421 will not work in case you don't use the correct polarity! If the Sentis3D-M421 doesn't work please check the power supply polarity first!

To ensure, that your Sentis3D-M421 works correctly, connect the Sentis3D-M421 to the **24V DC** power supply using connector **(a)** and wait for approximately 20 seconds until the camera boots up.

## 1.2.3 GBit Ethernet Connector (b)

This standard RJ45 connector provides a 10/100/1000 Base-T interface to the Sentis3D-M421.

Plug in the Ethernet cable **(b)** and connect your Sentis3D-M421 to your PC.



### 1.3 Overview of the Setup




Figure 1-2: Sentis3D-M421 with connected power supply and Ethernet cable



## 2 Downloading the Evaluation Software

Please point your browser to our support site <https://support.bluetechnix.com/> and select the 'Free Access' area.

### 2.1 Support website




Figure 2-1: Bluetechnix support site





## 2.2 Start-up screen




Figure 2-2: Start-up screen

Please select your product: Sentis3D-M421

On the product support page please download the latest software support package from the download section.

## 2.3 Prepare your Network Interface Card (NIC)

Once you have connected your Sentis3D-M421 to a Network Interface Card (NIC) of your PC give this NIC the IP-Address 192.168.0.1 with a subnet mask of 255.255.255.0.

No driver must be installed on your PC!

The Sentis3D-M421 uses IP-Address 192.168.0.10 with subnet mask 255.255.255.0.

### 3 Start using your Sentis3D-M421 with 'BitTofSuite'

Using this software you can simply display the depth image and the amplitude image of the Sentis3D-M421. For a detailed introduction to the software, please read the Bluetechnix ToF Suite – Manual included in the support package.

Place the Sentis3D-M421 on your desk approximately 50 cm in front of you.




Figure 3-1: Sample scenario with Sentis3D-M421

Browse to the directory where you previously saved the software support package zip file. Unzip the software. Browse to the tools directory. There you find the BitTofSuite. Start the BitTofSuite.

On how to use this software, connect and evaluate your product, please refer to the Bluetechnix ToF Suite user manual included in the software support package.



## 4 System Requirements & Support

- Operating System: Microsoft Windows 7/8/8.1/10
- 32 bit (x86) or 64 bit (x64) processor
- Dual-core 2 GHz or faster CPU
- Dedicated Ethernet port
- 2GByte RAM

### 4.1 Support

For answers to common questions, troubleshooting steps and further documentation visit our Bluetechnix support website <https://support.bluetechnix.at/wiki/>



## 5 Product History

### 5.1 Version Information

#### 5.1.1 Sentis3D-M421

Version	Release date	Firmware Version
X-Grade	March 2015	

Table 5.1: Overview Sentis3D-M421 product changes

Additional information can be found at <http://support.bluetechnix.com>

### 5.2 Anomalies

Version	Date	Description
0.0.0		No anomalies reported yet.

Table 5.2: Product anomalies

Additional information can be found at <http://support.bluetechnix.com>

### 5.3 Document Revision History

Version	Date	Document Revision
0	20150307	First draft
1	20150327	First released Issue
2	20160210	Removed BltTofSuite section
3	20160422	KIT renamed to Sentis3D-M421 Some typos corrected

Table 5.3: Revision history